

NTS @ A3



1. Helibar repair location on panel and detail as SK20
2. Wall repair:
 - a. Remove loose/hollow brickwork at wall base working in lengths <1m
 - b. Cut back visible roots and treat live ends to client specification.
 - c. Clean out hole and remove dust
 - d. Stitch in new masonry to architect's specification

BAY 6