



- Full plinth repair/reconstruction similar to High Street elevation:
- a. Remove loose/hollow brickwork/cement render at wall base working in lengths <1m to half brick thickness.
 - b. Cut back visible roots and treat live ends to client specification.
 - c. Clean out hole and remove dust
 - d. Stitch in new masonry to architect's specification. Fix with stainless steel wall ties plugged and screwed to retained masonry behind at 900mm c/c horizontally and 450mm c/c vertically.

BAY 8 & 9