




NOTES:

KEY

— REMOVAL

— EXISTING



REVISION HISTORY



Except for Planning purposes, figured dimensions only are to be taken from this drawing.
All dimensions are in millimetres unless otherwise stated.
All dimensions shall be checked on site prior to works commencing.
Any discrepancies shall be reported to the Architect.
© Copyright F3 Architecture + Design. All rights reserved.

Health and Safety

Refer to relevant Construction (Design and Management) documentation where applicable. The Contractor shall plan, manage and monitor the works inclusive of temporary erection stability. Any works that are found to be unstable in the temporary state are to be reported directly to the structural engineer and Main Contractor/ Package Manager in order to provide safe temporary support. Check on site prior to commencement of works/fabrication etc.

project

THE PRINTWORKS

819-829, HIGH ROAD, TOTTENHAM,
LONDON, N17 8ER

DEMOLITION ELEVATIONS EAST (819 and 821)

drawn by	scale	paper	project no
DG	1 : 50	A1	220428

status	revision
A2 - ISSUED FOR PLANNING	A2.P1

PRINT-F3A-ZZ-EX-EL-A-82514

Demolition Notes:

819-821 High Road

- General:
- Protect all existing surfaces adjacent work areas, which are to be retained, with timber board, ensure windows are protected.

1. Carefully remove cement copings to the parapet complete.
2. Carefully take down C20 chimney to sound course below existing corbeling ready for restoration.
3. Allow to investigate and remove unobtrusive sample section of paint to expose historic plaster for inspection.
4. Carefully remove paint to window sills complete, subject to trial investigations.
5. Allow to move modern timber boarding to expose historic shopfront.
6. Carefully remove satellite dish complete.
7. Carefully remove redundant cabling and services complete.
8. Allow to remove unsympathetic modern signage and timber barding complete.
9. Carefully remove defective lead flashing to shop front complete.
10. Carefully remove modern shop front. Extent as shown.
11. Carefully remove modern doors complete.
12. Allow to investigate existing timber for rot.
13. Carefully remove damaged stone to door threshold.
14. Allow to investigate and remove unobtrusive sample section of paint and render where cracked and loose. Assume replacement of 20% defective brick like for like.

