





NOTES:

INTERNAL LAYOUTS SHOWN FOR INDICATIVE PURPOSES ONLY

REVISION HISTORY



Refer to relevant Construction (Design and Management) documentation where applicable. The Contractor shall plan, manage and monitor the works inclusive of temporary erection stability. Any works that are found to be unstable in the temporary state are to be reported directly to the structural engineer and Main Contractor/ Package Manager in order to provide safe temporary support. Check on site prior to commencement of works/fabrication etc.

PROPOSED GA ROOF PLAN (819 - 829)

drawn by	scale	paper	project no
KB	1 : 100	A1	220428
status			revision
A2 - ISSUED FOR PLANNING			A2.P1
drawing no			
PRINT-F3A-ZZ-RF-GA-A-82108			